

US UK

Dear user

Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully.

1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.

2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty.

A: Cap indicator

M: Mode indicator

Battery indicator

WIN/MAC Type C port

2.4G OFF BT WIN MAC

2.4G/OFF/BT mode switch

2.4G receiver storage slot

O.S. Support

Windows XP/Vista/Win 7/Win 8/Win 10/Win 11/Mac O.S.

How to connect the keyboard with multi-ple devices

Wired Connection

1. 2.4G/OFF/BT switch on "OFF".

2. Connect the keyboard to computer with USB cable.

3. The computer will recognize and configure the keyboard automatically.

2.4G Wireless Connection

1. 2.4G/OFF/BT switch on "2.4G", the LED  flashes in Yellow, plug the USB receiver into your computer USB port, the keyboard will connect with computer automatically.

2. If auto-connection unsuccessfully, or you want to connect to new device, plug out the USB receiver, press and hold [FN]+[4] for 3 seconds, the LED  flashes in Yellow, plug the USB receiver into computer USB port, after paired the LED will turn to steady on.

Bluetooth Connection

1. 2.4G/OFF/BT switch on "BT".

2. Press and hold [FN]+[1/2/3] for 3 seconds,  flashes in Blue[1] or Cyan[2] or Pink[3] quickly.

3. Turn on Bluetooth function and searching for available device, It will find "BT3.0 Keyboard and BT5.0 Keyboard" device names. Select a Bluetooth name to pair, after paired the LED will turn to steady on.

4. To switch the Bluetooth connections between BT1/BT2/BT3, press [FN]+ [1/2/3].

Product Features

Backlight

1. The default 16 backlight patterns switch by press [FN] + [INS] to cycling switch the light patterns. Press [FN] + [Space bar] to turn ON/OFF backlight.

2. Press [FN] + [←/→] to adjust light rotating speed, total 5 levels.

Press [FN] + [↑/↓] to adjust backlight brightness, total 5 levels.

3. Backlight color switching: [FN] + [DEL] to cycling switch Red, Green, Blue, Yellow, Purple, Cyan, White, RGB.

4. Backlight DIY: Press [FN] + [Back space] to enter DIY mode, [ESC] [A] [S] [W] [D] [↑] [↓] [←] [→] lights on by default, Press [FN] + [Back space] again to start recording, "CAPS" LED will flashing till the recording completed, Continuously press the key to select the color you want to set, once key light color setting are completed, press [FN] + [Back space] to save.

[WIN] lock

Press [FN] + [WIN] to lock [WIN] key, repeat to unlock (DO NOT lock the key when using on MAC O.S.)

[W] [S] [A] [D] & [↑] [↓] [←] [→] swap

Press [FN] + [W], the function [W] [S] [A] [D] and [↑] [↓] [←] [→] keys will be swapped, repeat to recovery.

Windows / MAC shortcut keys switching

Use MAC/WIN switch on the front side of keyboard.

Commands of key combinations with [FN] key

WINDOWS O.S.	MAC O.S.
FN+F1: Screen brightness -	F1: Screen brightness -/ FN+F1=F1
FN+F2: Screen brightness +	F2: Screen brightness +/ FN+F2=F2
FN+F3: Multiple windows	F3: Multiple task / FN+F3=F3
FN+F4: Speech recognition (O.S. win10 or newer)	F4: Siri / FN+F4=F4
FN+F5: Show desktop	F5: Show desktop / FN+F5=F5
FN+F6: Search	F6: Search / FN+F6=F6
FN+F7: Pre track	F7: Pre track / FN+F7=F7
FN+F8: Play/Pause	F8: Play/Pause / FN+F8=F8
FN+F9: Next track	F9: Next track / FN+F9=F9
FN+F10: Mute	F10: Mute / FN+F10=F10
FN+F11: Volume -	F11: Volume down / FN+F11=F11
FN+F12: Volume +	F12: Volume up / FN+F12=F12

Restore factory settings

Press and hold [FN] + [ESC] for 3 seconds.

Power save mode & How to recharge

On wireless/BT connection mode, when keyboard without any operation over 3 minutes, the keyboard backlight will turn off to save the battery, when keyboard without any operation over 30 minutes, the keyboard will enter power save mode, press any key to wake up.

When battery is low, the backlight will turn off, the power LED will blink red slowly when pressed a key.

Connect the keyboard with computer for charging, the power LED will steady on Red when charging, after fully charged turn to steady on Green.

Battery power indicator: Press and hold [FN] + [] to show the battery level, release to back to current backlight mode.

FAQ

1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer.

2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use.

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.

DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.

DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.

DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.

DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.

DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

CAUTION:

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference received, including interference that may cause undesired operation of the device.

Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

PL

Drogi Użytkowniku

Dziękujemy za wybranie marki REDRAGON . Aby chronić swoje prawa i korzystać z lepszej obsługi klienta, zwróć uwagę na nasze warunki gwarancji.

1. W okresie gwarancji naprawa jest objęta gwarancją w przypadku awarii spowodowanej problemami z obwodami elektrycznymi. Nie uwzględnia się szkód spowodowanych przez człowieka, takich jak demontaż, silne uderzenia, zanurzenie w wodzie, podłączanie do niewłaściwego prądu lub napięcia ani szkód spowodowanych przez kłęski żywiołowe, takie jak pożar, powódź lub trzęsienie ziemi.

2. Części eksploatacyjne (np. stopka) oraz części zamienne nie są objęte naszą gwarancją.

Obsługiwane systemy operacyjne

WinXP/Vista/Win7/Win8/Win10 /Win11 /Mac O.S.

Jak podłączyć klawiaturę do wielu urządzeń

Połączenie przewodowe

1. Ustaw 2.4G/OFF/BT na „OFF”.

2. Podłącz klawiaturę do komputera za pomocą kabla USB.

3. Komputer automatycznie rozpozna i skonfiguruje klawiaturę.

Połączenie bezprzewodowe 2.4G

1. Przełącznik 2.4G/OFF/BT ustaw na „2.4G”, dioda LED  zacznie migać na żółto, podłącz odbiornik USB do portu USB w komputerze, a klawiatura połączy się z komputerem automatycznie.

2. Jeśli automatyczne połączenie się nie powiedzie lub chcesz połączyć się z nowym urządzeniem, wyjmij odbiornik USB, przytrzymaj[FN]+[4] przez 3 sekundy, dioda LED  zacznie migać na żółto, podłącz odbiornik USB do portu USB w komputerze, po sparowaniu dioda LED zaświeci się na stałe.

Połączenie Bluetooth

1. Ustawić 2.4G/OFF/BTna „BT”.

2. Naciśnij i przytrzymaj [FN]+[1/2/3] przez 3 sekundy,  szybko miga na niebiesko [1] lub w kolorze cyjan [2] lub różowym [3].

3. Włącz funkcję Bluetooth i wyszukaj dostępne urządzenia. Znajdziesz tam nazwy urządzeń „BT3.0 Keyboard” oraz „BT5.0 Keyboard”. Wybierz nazwę Bluetooth do sparowania, po czym dioda LED zaświeci się na stałe.

4. Aby przełączyć połączenia Bluetooth między BT1/BT2/BT3, naciśnij [FN] + [1/2/3].

Cechy produktu

Podświetlenie

1. Domyślne 16wzorów podświetleniamożna zmienić, naciskając [FN] + [INS], aby przełączać się między wzorami. Naciśnij [FN] + [spacja], aby włączyć lub wyłączyć podświetlenie.

2. Naciśnij [FN] + [←/→], aby dostosować prędkość rotacji podświetlenia, dostępnych jest 5 poziomów.

Naciśnij [FN] + [↑/↓] , aby dostosować jasność podświetlenia. Dostępnych jest 5 poziomów.

3. Zmiana koloru podświetlenia: [FN] + [DEL] do przełączania między kolorami: czerwony, zielony, niebieski, żółty, fioletowy, cyjan, biały, RGB.

4. Personalizacja podświetlenia: Naciśnij[FN] + [Backspace], aby wejść w tryb DIY, domyślnie świecą się klawisze [ESC] [A] [S] [W] [D] [↑] [↓] [←] [→]. Ponownie naciśnij[FN] + [Backspace], aby rozpocząć nagrywanie, „CAPS” dioda LED będzie migać do zakończenia nagrywania. Naciśkać klawisz, aby wybrać kolor, który chcesz ustawić. Po zakończeniu ustawiania koloru podświetlenia klawisza, naciśnij[FN] + [Backspace], aby zapisać.

Blokada klawisza [WIN]

Naciśnij [FN] + [WIN], aby zablokować klawisz [WIN], ponownie naciśnij, aby go odblokować (NIE blokuje klawisza podczas używania na systemie MAC O.S.)

Zamiana [W] [S] [A] [D] z [↑] [↓] [←] [→]

Naciśnij [FN] + [W], aby zamienić funkcje klawiszy [W] [S] [A] [D] z [↑] [↓] [←] [→], ponowne naciśnięcie przywróci ustawienia.

Skróty klawiszowe przełączania Windows / MAC

Użyj przełącznika MAC/WIN znajdującego się z przodu klawiatury.

Polecenia kombinacji klawiszy z klawiszem [FN]

WINDOWS	MAC O.S.
FN+F1: Jasność ekranu -	F1: Jasność ekranu -/ FN+F1=F1
FN+F2: Jasność ekranu +	F2: Jasność ekranu +/ FN+F2=F2
FN+F3: Przełączanie między oknami	F3: Wiele zadań / FN+F3=F3
FN+F4: Rozpoznawanie mowy (system Windows 10 lub nowszy)	F4: Siri / FN+F4=F4
FN+F5: Pokaż pulpit	F5: Pokaż pulpit / FN+F5=F5
FN+F6: Wyszukiwanie	F6: Wyszukiwanie / FN+F6=F6
FN+F7: Poprzedni utwór	F7: Poprzedni utwór / FN+F7=F7
FN+F8: Odtwarzaj/pauza	F8: Odtwórz/Pauza / FN+F8=F8
FN+F9: Następnyutwór	F9: Następnyutwór / FN+F9=F9
FN+F10: Wycisz	F10: Wycisz / FN+F10=F10
FN+F11: Zmniejsz głośność	F11: Zmniejsz głośność / FN+F11=F11
FN+F12: Zwiększ głośność	F12: Zwiększ głośność / FN+F12=F12

Przywróć ustawienia fabryczne

Naciśnij i przytrzymaj [FN] + [ESC] przez 3 sekundy.

Tryb oszczędzania energii i jak ładować

W trybie połączenia bezprzewodowego/BT, gdy klawiatura nie jest używana przez ponad 3 minuty, podświetlenie klawiatury wyłączy się, aby oszczędzać baterię. Jeśli klawiatura pozostaje nieużywana przez ponad 30 minut, przejdzie w tryb oszczędzania energii. Naciśnij dowolny klawisz, aby ją wybudzić.

Gdy bateria jest słaba, podświetlenie się wyłączy, a dioda zasilania zacznie powoli migać na czerwono po naciśnięciu klawisza.

Podłącz klawiaturę do komputera, aby ją naładować. Podczas ładowania dioda zasilania świeci się na czerwono. Po pełnym naładowaniu zmienia kolor na zielony.

Wskaźnik poziomu naładowaniabaterii: Przytrzymaj[FN] + [], aby wyświetlić poziom baterii, a następnie puść, aby powrócić do bieżącego trybu podświetlenia.

Często zadawane pytania

1. Jeśli klawiatura nie odpowiada, sprawdź, czy kabel USB klawiatury jest prawidłowo podłączony do odpowiedniego złącza USB w komputerze lub spróbuj użyć innego złącza USB w komputerze.

2. W przypadku rozlania płynu na klawiaturę należy natychmiast odłączyć kabel klawiatury USB od komputera. Wytrzyj nadmiar płynu i umieść klawiaturę w ciepłym i przewiewnym miejscu. Przed następnym użyciem upewnij się, że klawiatura naturalnie wyschła.

REDRAGON

STAR BLADE PRO

REDRAGON 3 MODES

CONNECTIONS BACKLIGHTING GAMING KEYBOARD

Please scan here to download user manual

Mechanical Gaming Keyboard

User manual

封底

封面

型号	K707WBP-RGB-PRO/7227	备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷		文件编号	A.1
名称	说明书				
日期	2024-12-24				
页码	1 OF 1	文件编号			
绘图	雷国建	审核	香敏琪	核准	版本

Easternimes

tech