



REDRAGON

AZZMACH WIRED LIGHT WEIGHT GAMING MOUSE



Please scan here to download operating instructions



Wired Light weight Gaming Mouse Operating Instructions

US UK


Dear user

Thank you for choosing our REDRAGON product. To protect your rights and for better customer service, we ask that you note our warranty rules.

- 1. Within guaranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
2. Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

Button Instructions

- 1. Left button
2. Right button
3. Scroll wheel (Click as middle button)
4. Side button, defaulted forward
5. Side button, defaulted backward
6. DPI button
7. Profile switch button



1

Connection

Connect the mouse to the computer with USB cable, computer will recognize and configure the mouse automatically.

DPI adjustment and indication

Default DPI indicator color (LED on the bottom), M618 support max 10000 DPI(adjust through software).

- 1. RED ----- 400 DPI
2. BLUE ----- 800 DPI
3. GREEN ----- 1600 DPI
4. PURPLE ----- 2400 DPI
5. YELLOW --- 3200 DPI

Report rates adjustment

The mouse supports adjust report rates [125Hz-250Hz-500Hz-1000Hz], through mouse software to set the report rates.

For more adjustable functions, backlight setting and macro recording, please download& install mouse software to enable more possibility.

FAQ

- 1. If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.
2. If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.



2

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

- 1. Cleaning Instructions: Before cleaning, always unplug the device from the computer's USB port. Clean the surfaces with a soft, dry cloth. For stubborn dirt, use a cloth that is slightly dampened with water. Do not use chemical agents or solvents.
2. Ergonomic Health and Safety Guide: Incorrect or prolonged use of computer equipment can lead to discomfort, fatigue, headaches and serious long-term injuries known as musculoskeletal disorders (MSDs). Please take relaxation breaks every 30-60 minutes.
3. WARNING: The product is not a toy. Please keep it out of reach of small children. The product contains small components that may pose a choking hazard.

3

RU


Уважаемый пользователь

спасибо за выбор марки REDRAGON. С целью защиты ваших прав и для более качественного обслуживания мы просим учитывать наши условия гарантии.

- 1. В течение гарантийного периода гарантия распространяется на устранение повреждений, вызванных проблемами в электрической цепи. Повреждения, произошедшие по вине человека, такие как разборка, жесткие удары, погружение в воду, подключение к цепи с ненормативным током или напряжением, а также ущерб, вызванный стихийными бедствиями, включая пожар, наводнение или землетрясение, в условия гарантии не включены.
2. Расходные детали (например, pedal для ног) и работы по замене запасных частей в гарантию не включены.

Инструкция по использованию кнопки

- 1. Левая кнопка
2. Правая кнопка
3. Колесо прокрутки (нажатие как средняя кнопка)
4. Боковая кнопка, по умолчанию направлена вперед.
5. Боковая кнопка, по умолчанию перевернутая.
6. Кнопка DPI
7. Кнопка переключения профиля



4

Связь

Подключите мышь Подключите мышь к компьютеру с помощью USB-кабеля, компьютер автоматически распознает и настроит ее

Регулировка DPI и индикация

Цвет индикатора DPI по умолчанию (светодиод внизу), M618 поддерживает максимальное разрешение 10000 DPI (настраивается программно).

- 1. КРАСНЫЙ ----- 4,00 Д ПИ
2. СИНИЙ ----- 8,00 Д ПИ
3. ЗЕЛЕНый ----- 16,00ДПИ
4. ФИОЛЕТОВЫЙ --- 24,00 DPI
5. ЖЕЛТЫЙ ----- 32,00 DPI

Корректировка тарифов отчетности

Поддержка мыши позволяет регулировать частоту опроса [125 Гц-250 Гц-500 Гц-1000 Гц] с помощью программного обеспечения мыши.

Для более гибкой настройки функций , параметров подсветки и записи макросов, пожалуйста, загрузите и установите программное обеспечение для мыши, чтобы расширить возможности.

Часто задаваемые вопросы

- 1. Если мышь не реагирует, проверьте, правильно ли она подключена.Подключитесь к соответствующему USB-порту компьютера или попробуйте другой USB-порт.
2. Если курсор мыши движется медленно, скачет или с задержкой, попробуйте другую поверхность.Темные, грязные, неровные, светлые поверхности могут влиять на работу мыши.Настоятельно рекомендуется использовать подкладку.



5

Table with 5 columns: Model (型号), Name (名称), Date (日期), Page (页码), Drawing (绘图), Remarks (备注), File Number (文件编号), Approval (核准), Version (版本). Contains product details for Redragon M618 mouse.

