


REDRAGON
AZZMACH LITE
3 MODES CONNECTION LIGHT-WEIGHT
GAMING MOUSE



Please scan here to download operating instructions

3 Modes Connection Light-weight Gaming Mouse
Operating Instructions

US UK

Dear user

Thank you for choosing our **REDRAGON** product. To protect your rights and for better customer service, we ask that you note our warranty rules.


- Within warranty period, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included.
- Consumable parts (such as foot pad) and spare parts replacement are not included in our warranty.

CAUTION:

Important Safety Note: For transportation and storage safety, the battery of this product is shipped at a reduced charge level. If you encounter insufficient battery upon first use, please fully charge the device before operation.

Button Instructions

- Left button
- Right button
- Scroll wheel (Click as middle button)
- Side button, defaulted forward
- Side button, defaulted backward
- DPI
- 2.4G/BT pair
- BT/OFF/2.4G switch



BT Connection

Default DPI indicator color (LED on the bottom), M618-LIT support max 10000 DPI (adjust through software).


- RED ----- 400 DPI
- BLUE ----- 800 DPI
- GREEN ---- 1600 DPI
- CYAN ----- 2400 DPI
- PURPLE --- 4000 DPI

Wired Connection

[BT/OFF/2.4G] switch on "OFF"; connect the mouse to computer with USB cable. The computer will recognize and configure the mouse automatically; the mouse battery will be charging at same time.


2.4G Wireless Connection

- [BT/OFF/2.4G] switch on "2.4G";
- Plug the USB receiver into the USB port on your computer, the computer will recognize and configure the mouse automatically.

TIP: If auto-connection unsuccessfully, or you want to connect new device, plug out USB receiver from current device USB port, turn off the mouse, then switch to "2.4G"; press & hold  for 3s, the mouse enter pairing status, LED indicator flash quickly in Green, plug USB receiver into device USB port, LED indicator turn to steady on about 2s then turn off, the mouse are connected.

2.4G Wireless Connection


- [BT/OFF/2.4G] switch on "2.4G";
- Plug the USB receiver into the USB port on your computer, the computer will recognize and configure the mouse automatically.

TIP: If auto-connection unsuccessfully, or you want to connect new device, plug out USB receiver from current device USB port, turn off the mouse, then switch to "2.4G"; press & hold  for 3s, the mouse enter pairing status, LED indicator flash quickly in Green, plug USB receiver into device USB port, LED indicator turn to steady on about 2s then turn off, the mouse are connected.

Taxa de leitura	O LED pisca
125Hz	flash 1 times
250Hz	flash 2 times
500Hz	flash 3 times
1000Hz	flash 4 times

(Reading speed adjustment is not available in BT mode, 125Hz being the default)

BT Connection





BT
OFF
2.4G

Auto sleep and power save function

The mouse will enter sleep mode when it is out of operation in 3 minutes, move or click any button to wake it up, when the mouse is out of operation in 10 minutes, the mouse will enter power save mode, click any button to wake it up.


How to recharge the battery

 Low battery warning—the scroll wheel LED will twinkling in red when the battery is low.
 Use the USB cable to connect to PC USB port to charge the battery, the scroll wheel LED will steady on in red, after battery fully charged the LED turns to current DPI color.

Warning: Charging current: 5V = 1A max.
Do not use a fast charger to recharge the mouse!
Built-in lithium-ion battery, 1 unit.

FAQ

- If the mouse is not responding, please check whether the mouse is plugged correctly in the corresponding computers USB port, or try another USB ports.
- If the mouse is moving slowly, jumping or with delay, please try another surface. Dark, dirty, un-flat, bright surfaces may affect the performance of mouse. Mouse pad strongly recommended.



FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) This device may not cause harmful interference, and
 (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 Reorient or relocate the receiving antenna.
 Increase the separation between the equipment and receiver.
 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

ISED WARNING

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
 (1) This device may not cause interference.
 (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.
 L'exploitation est autorisée aux deux conditions suivantes:
 (1) L'appareil ne doit pas produire de brouillage, et
 (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. Appareil numérique du CIEM conforme

- Cleaning Instructions:** Before cleaning, always unplug the device from the computer's USB port. Clean the surfaces with a soft, dry cloth. For stubborn dirt, use a cloth that is slightly dampened with water. Do not use chemical agents or solvents. Ensure the devices are completely dry before reconnecting them.
- Ergonomic Health and Safety Guide:** Incorrect or prolonged use of computer equipment can lead to discomfort, fatigue, headaches and serious long-term injuries known as musculoskeletal disorders (MSDs). Please take relaxation breaks every 30-60 minutes.
- WARNING:** The product is not a toy. Please keep it out of reach of small children. The product contains small components that may pose a choking hazard.

BATTERY SAFETY GUIDELINES

DO NOT replace the battery with a different model.
 DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material.
 DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes.
 DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition.
 DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations.
 DO NOT impact, bend, alter, disassemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful.

CAUTION

Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock.

RU

Уважаемый пользователь

спасибо за выбор марки **REDRAGON**. С целью защиты ваших прав и для более качественного обслуживания мы просим учитывать наши условия гарантии.

- В течение гарантийного периода гарантия распространяется на устранение повреждений, вызванных проблемами в электрической цепи. Повреждения, произошедшие по вине человека, такие как разборка, жесткие удары, погружение в воду, подключение к цепи с ненормативным током или напряжением, а также ущерб, вызванный стихийными бедствиями, включая пожар, наводнение или землетрясение, в условия гарантии не включены.
- Расходные детали (например, педаль для ног) и работы по замене запасных частей в гарантии не включены.

ВНИМАНИЕ:

Важное примечание по технике безопасности: В целях безопасности при транспортировке и хранении батарей данного изделия поставляется с пониженным уровнем заряда. Если при первом использовании вы обнаружите недостаток заряда батареи, пожалуйста, полностью зарядите устройство перед началом работы.

Описание кнопок

- Левая кнопка
- Правая кнопка
- Колесо прокрутки (при нажатии работает как средняя кнопка)
- Боковая кнопка, функция по умолчанию: вперед
- Боковая кнопка, функция по умолчанию: назад
- Кнопка выбора разрешения DPI
- Кнопка сопряжения
- Выключатель питания/Выбор режима: BT/ВЫКЛ/2,4 ГГц



Проводное подключение


Подключите мыш к компьютеру с помощью USB-кабеля в любом режиме подключения, мыш перейдет в режим проводного подключения. Компьютер автоматически распознает и настроит мыш, при этом начнется ее зарядка.

Беспроводное подключение на частоте 2,4 ГГц

Вставьте USB-ресивер в USB-порт компьютера, переведите переключатель режимов [BT/OFF/2.4G] в положение "2.4G", нажмите любую кнопку и компьютер распознает и настроит мыш автоматически.

Подключение по BT

Переведите переключатель [BT/OFF/2.4G] в положение "BT", индикатор начнет быстро мигать синим, нажмите кнопку  и удерживайте 3 секунды, чтобы выбрать режим сопряжения по BT. Включите на компьютере функцию BT и выполните поиск доступных устройств. Выберите имя устройства "BT 5.1 Mouse", далее компьютер выполнит автоматическое распознавание и настройку мыши.



BT
OFF
2.4G


Настройка разрешения DPI и индикация

Нажмите кнопку DPI для циклического переключения уровня разрешения 400DPI/800DPI/1600DPI/2400DPI/4000DPI. При настройке уровня DPI индикатор DPI будет мигать, как показано ниже:

КРАСНЫЙ ----- 400 DPI
 СИНИЙ ----- 800 DPI
 ЗЕЛЕНый ----- 1600 DPI
 ГОЛУБОЙ ----- 2400 DPI
 ФИОЛЕТОВЫЙ --- 4000 DPI

Максимальное разрешение мыши составляет 10000 DPI, для настройки загляните и установите ПО мыши.

Настройка частоты опроса и индикация

Нажмите кнопки  и , для циклического выбора частоты опроса 125 Гц/250 Гц/500 Гц/1000 Гц. При настройке частоты опроса индикатор будет мигать белым цветом, как описано ниже:

Частота опроса	Кол-во миганий
125 Гц	1
250 Гц	2
500 Гц	3
1000 Гц	4

(Настройка частоты опроса недоступна в режиме BT, по умолчанию 125 Гц)

Автоматический режим сна и энергосбережение

Если мышью не пользоваться в течение 3 минут, она переходит в режим ожидания. Переместите мыш, или нажмите любую кнопку, чтобы разбудить ее. Если мышью не пользоваться в течение 10 минут, включается режим сна, также нажмите любую кнопку, чтобы разбудить мыш. Если вы не собираетесь использовать мыш в течение длительного времени, переведите переключатель на нижней панели в положение OFF, чтобы сфиксировать ее заряд.


Зарядка аккумулятора

1. Предупреждение о разрядке аккумулятора – при низком заряде индикатор DPI будет мигать красным цветом.
 Для зарядки аккумулятора подключите мыш к компьютеру с помощью кабеля USB Type-C, индикатор DPI будет постоянно гореть красным цветом, а после полной зарядки аккумулятора цвет индикатора изменится на установленный по умолчанию.

Предупреждение: Сила тока зарядки: 5 В = 1А макс.
НЕ используйте адаптер с быстрой зарядкой для зарядки вашей мыши!
Встроенный литий-ионный аккумулятор – 1 шт.

Часто задаваемые вопросы

- Если мыш не отвечает, убедитесь в том, что мыш подключена правильно в соответствующий USB-порт на компьютере, также попробуйте использовать другую USB-порт.
- Если курсор движется медленно, рывками или прерывисто, попробуйте использовать другую поверхность. Темные, грязные, неровные, яркие поверхности могут ухудшить работу мыши. Поэтому настоятельно рекомендуется использовать коврик для мыши.





型号	红龙 M618-LIT 4115		备注:	尺寸: L100*W100mm 材质: 80g书写纸, 风琴折页, 正反印 印刷: 单色
名称	说明书(英+俄)		文件编号	
日期	2026-4-7		审核	
页码	1 OF 1		核准	
绘图	吴九香	审核	香敏琪	版本 A.0

